


Getting Started





Key Description

The following table describes the keys on the 6867i:

| | <u> </u> |
|--------------|---|
| Key | Description |
| T | Goodbye Key - Ends an active call. The Goodbye key also exits an open list, such as the Options List, without saving changes. |
| € v | Hold Key - Places an active call on hold. To retrieve a held call, press the Hold key again or press the Pickup softkey offered on the display. |
| * | Options Key - Accesses services and options to customize your phone. Your System Administrator may have already customized some of your settings. Check with your System Administrator before changing any Administrator-only options. |
| # | Mute Key - Mutes the microphone so that your caller cannot hear you (the light indicator flashes when the microphone is on mute). |
| → → ® | Volume Controls - Adjusts the volume for the handset, ringer, and handsfree speakerphone. |
| 2 | Callers List Key - Accesses a list of the last 200 calls received. |
| ‡ | Redial Key - Accesses a list of the last 100 previously dialed numbers. Pressing the Redial key twice redials the last dialed number. |
| L2 | Line/Call Appearance Keys - Connects you to a line or call. The Aastra 6867i IP phone has two default Line keys, each with LED indicator lights. |
| d/9 | Speaker/Headset Key - Transfers the active call to the speaker or headset, allowing handsfree use of the phone. |
| Ф | Directory Key - Accesses a directory of names and phone numbers (stored in alphabetical order). |
| | Navigation Keys/Select Button - Multi-directional navigation keys allow you to navigate through the phone's user interface. Pressing the center Select button selects/sets options and performs various actions (such as dialing out when in the Directory, Callers, and Redial Lists). |
| <u>4</u> - | Transfer Key - Transfers the active call to another number. |



Basic Call Handling

Placing a Call

- 1. Lift the handset, press a **Line** key, or press the key.
- Dial the number from the keypad and press the Dial softkey.



Place the handset on its cradle or press the key.



Answering a Call

Lift the handset for handset operation or press the **Line** key or description key for handsfree operation.

Ignoring a Call

Press the key or **Ignore** softkey when the phone is ringing to ignore the incoming call and (if configured) send the incoming call directly to voicemail.

Redialing

Press the key once to access a list of recently dialed numbers. Use the **Up** and **Down** navigation keys to scroll through the entries and the **Select** key (or **Dial** softkey) to redial the selected number. Press the key twice to call the last dialed number.

Muting

Press the key to mute the handset, headset, or speakerphone.

Holding and Resuming

- 1. To place a call on hold, press the key when connected to the call.
- 2. To resume the call, press the \(\bigcup_{\pi} \) key again or press the \(\bigcup_{\pi} \) key corresponding to the line where the call is being held.



User Interface (UI) Overview

Home Screen

The Home Screen displays the date and time along with various important status messages. It is the default screen displayed when the phone is in an idle state.



Line Selection Screen

The Line Selection Screen allows you to easily view the lines in use and select a line to act upon.



When a line is not in use, a New Call key is available allowing you to dial out using the selected line.



Advanced Call Handling

The 6867i IP phone provides simple and convenient methods for transferring calls and establishing conference calls.

Note:

Transferring and conferencing can be initiated in both the Multi-View and Detailed-View Call Screens.

Call Transferring

| 1. | Ensure you are on active call with the party you wish to transfer. |
|----|--|
| | If you are already connected to the transfer recipient, press the Up or Down |
| | navigation keys to highlight the recipient and press the key or Xfer softkey to complete the call transfer. |
| | OR |
| | If you are not connected to the transfer recipient, press the key or Xfer softkey, enter the recipient's number and press the Dial softkey. At any time, press the |

3-Way Conferencing

 Ensure you are on active call with one of the parties with whom you wish to create a conference.

key or **Xfer** softkey again to complete the call transfer.

2. If you are already connected to the party you wish to conference in, press the Up or Down navigation keys to highlight the conference target and press the Conf softkey to complete the 3-way conference.
OR

If you are not connected to the party you wish to conference in, press the key or **Conf** softkey, enter the conference target's number and press the **Dial** softkey. At any time, press the key or **Conf** softkey again to complete the 3-way conference.

Note:

If the 3-way conference is successful, in icons will be displayed in the call status indicator area of both conference participants.



Using the Directory

- 1. Press the key to access the Directory.
- 1. Scroll through the list by pressing the **Up** or **Down** navigation keys or enter characters using the keypad to use the search feature.
- 2. When the desired entry is highlighted, press the Select key to place a call using the entry's default phone number. If you would like to place a call to a different phone number attached to the entry (if applicable), press the Right navigation key, highlight the desired phone number using the Up or Down navigation keys, and press the Select key.

Using the Callers List

- 1. Press the key to access the Callers List.
- Scroll through the list by pressing the Up or Down navigation keys. If you would like to view additional entry details, press the Right navigation key.
- 3. Press the Select key to place a call to the respective entry.



Call Forward in Phone Mode



IP Phone UI

1. Press the configured Call Fwd softkey or press , navigate to the Call Forward option and press the button or **Select** softkey.



- 2. Enter forwarding numbers using the dialpad keys for any of the following states:
 - All: Forwards all incoming calls for the respective account to the specified number.
 - Busy: Forwards incoming calls to a specified number if DND has been enabled for that account OR if the account is currently engaged in another call.
 - · No Answer: Forwards incoming calls to a specified number if the call has not been answered for the specified number of rings.

- Pressing the ▼ navigation key moves the selection to the next field/checkbox.
- · If All and Busy and No Answer are all enabled (and/or if the account has DND enabled), the All settings take precedence over Busy and No Answer.
- Pressing the CopyToAll key copies the call forward number of the Call Forward mode in focus to every Call Forward mode of that account. For example, if you have the cursor pointing at the All state and has a call forward phone number configured, pressing the CopytoAII key assigns the same phone number to the Busy and No
- 3. If configuring a forwarding number for the No Answer state, navigate to the No. Rings field and press the ◀ or navigation keys to change the desired number of rings.
- Using the ▼ navigation key, move to the On checkbox beside the respective Call Forward mode and press the button to enable the Call Forward mode.



Press the Save softkey to save your changes.

In Phone mode, the configuration applies to all the accounts on the phone.